


TECHNICAL NOTE EXTERNAL POWER ADAPTOR

IMPORTANT

Install the external power adapter in accessible service friendly location. External power adaptors are to be installed on a steady flat surface, do not hang nor cover.

External power adaptors require a minimum air volume to avoid overheating and proper long-lasting operations. Allow at least 10 cm around a 12V DC model or 20 cm all around a 24V DC model.

If you require extension cables for your installation, please add these to your order; more information in regards to available extension cables can be found on our website.



Failing to do so will dramatically reduce lifetime of the unit and warranty claims will be refused.